



### Cacerola vapor

Panier vapeur  
Dampfkoch-Aufsatz  
Steam casserole  
Çaçarola a vapor

Ref.	€	Ø Cm.	H. Cm.	l t.
72420	33,40	20	8,5	2,50
72424	39,00	24	9,5	3,50
72428	44,50	28	11,0	6,50



### Conjunto cacerola vapor

Ensemble cuit vapeur  
Dampfkoch-Aufsatz Set  
Steam casserole set  
Conjunto caçarola a vapor

Ref.	€	Ø Cm.	H. Cm.	l t.
72421	79,60	20	15,5	2,50
72425	94,00	24	16,0	3,50



### Colador esférico

Passoire à queue  
Seiher, mit Stiel  
Strainer  
Coador esférico

Ref.	€	Ø Cm.	H. Cm.
72318	26,00	18	8,5



### Escurridera

Passoire sur pied  
Abtropfschüssel  
Colander with stand  
Escorredor

Ref.	€	Ø Cm.	H. Cm.
72324	38,50	24	11,0



### Cuecepastas sin tapa

Cuit-pâte sans couvercle  
Nudelkoch-Einsatz ohne Deckel  
Pasta cooker without lid  
Coze-massas sem tampa

Ref.	€	Ø Cm.	H. Cm.	l t.
72423	54,30	24	17,5	9,50



### Tartera con tapa

Plat rond avec couvercle  
Pfanne m/Deckel  
Round dish with lid  
Tarteira com tampa

Ref.	€	Ø Cm.	H. Cm.	l t.
72620	45,40	20	6,5	2,00
72624	53,80	24	7,0	3,00
72628	68,10	28	8,0	4,50
72632	89,80	32	8,0	6,00



### Sautex

Sauteuse  
Sauteuse  
Sauteuse  
Frigideira

Ref.	€	Ø Cm.	H. Cm.	l t.
72625	39,80	24	7,0	3,00
72629	49,70	28	8,0	4,50



### Tapa

Couvercle  
Deckel  
lid  
Tampa

Ref.	€	Ø Cm.
72916	10,10	16
72918	11,10	18
72920	13,20	20
72924	15,40	24
72928	20,00	28
72932	21,70	32