



RUBÍ



KUTAHYA
PORSELEN



RUBÍ



KUTAHYA
PORSELEN



RUBÍ

PLATO 22 CM. HONDO PORCELANA DECORADO RUBI



Ref: IEKR1001

Cod. E.A.N.: 8425558991334

U. caja: 12

E. caja: 0

TAZA 8 CLS. MOKA CON PLATO DECORADO RUBI



Ref: IEKR1016

Cod. E.A.N.: 8425558991488

U. caja: 6

E. caja: 0

FUENTE OVAL 32 CM. PORCELANA DECORADO RUBI



Ref: IEKR1009

Cod. E.A.N.: 8425558991419

U. caja: 6

E. caja: 0

PLATO 27 CM. LLANO PORCELANA DECORADO RUBI



Ref: IEKR1002

Cod. E.A.N.: 8425558991341

U. caja: 12

E. caja: 0

TAZA 10 CLS. CAFE CON PLATO DECORADO RUBI




Ref: IEKR1015

Cod. E.A.N.: 8425558991471

U. caja: 6

E. caja: 0

FUENTE OVAL 22 CM. PORCELANA DECORADO RUBI



Ref: IEKR1008

Cod. E.A.N.: 8425558991402

U. caja: 6

E. caja: 0

PLATO 20 CM. POSTRE PORCELANA DECORADO RUBI



Ref: IEKR1003

Cod. E.A.N.: 8425558991358

U. caja: 12

E. caja: 0

TAZA 18 CLS. TE CON PLATO DECORADO RUBI



Ref: IEKR1014

Cod. E.A.N.: 8425558991464

U. caja: 6

E. caja: 0

TETERA 0,35 L. PORCELANA DECORADO RUBI



Ref: IEKR1011

Cod. E.A.N.: 8425558991433

U. caja: 6

E. caja: 0

BAJO PLATO 30 CM. PORCELANA DECORADO RUBI



Ref: IEKR1005

Cod. E.A.N.: 8425558991372

U. caja: 6

E. caja: 0

TAZA 25 CLS. DESAYUNO CON PLATO DECORADO RUBI



Ref: IEKR1013

Cod. E.A.N.: 8425558991457

U. caja: 12

E. caja: 0

LECHERA 0,15 L. PORCELANA DECORADO RUBI



Ref: IEKR1012

Cod. E.A.N.: 8425558991440

U. caja: 6

E. caja: 0

PLATO 17 CM. PAN PORCELANA DECORADO RUBI



Ref: IEKR1004

Cod. E.A.N.: 8425558991365

U. caja: 12

E. caja: 0

TAZA 30 CLS. CONSOME CON ASAS DECORADO RUBI



Ref: IEKR1017

Cod. E.A.N.: 8425558991495

U. caja: 6

E. caja: 0

CENICERO REDONDO PORCELANA DECORADO RUBI



Ref: IEKR1010

Cod. E.A.N.: 8425558991426

U. caja: 24

E. caja: 0

BOWL 14 CM. SOPA PORCELANA DECORADO RUBI



Ref: IEKR1006

Cod. E.A.N.: 8425558991389

U. caja: 12

E. caja: 0

ENSALADERA 23 CM. PORCELANA DECORADO RUBI



Ref: IEKR1007

Cod. E.A.N.: 8425558991396

U. caja: 6

E. caja: 0