

Victoria



Referencia	Artículo	Uds. por caja
101260-2736	PLATO LLANO 26 Cm.	12
101280-2738	PLATO LLANO 28 Cm.	6
101320-2769	PLATO LLANO 32 Cm.	6
103190-2730	PLATO POSTRE 19 Cm.	24
103210-2731	PLATO POSTRE 21 Cm.	12
104170-2728	PLATO PAN 17 Cm.	12
102230-2720	PLATO HONDO 23 Cm.	12
103260-2825	PLATO DE POSTRE HONDO	6



122130-2714	ENSALADERA 13 Cm.	12
122180-2718	ENSALADERA 18 Cm.	24
122230-2723	ENSALADERA 23 Cm.	6



Referencia	Artículo	Uds. por caja
107080-2870	TAZA 0,08 L.	36
107160-2800	TAZA 0,16 L.	
107190-2806	TAZA 0,19 L.	36
107300-2817	TAZA CONSOME 0,32 L.	24
105125-2871	PLATILLO 12,5 Cm.	36
105155-2815	PLATILLO 15,5 Cm.	36
105170-2816	PLATILLO 17 Cm.	36



123270-2764	SOPERA 2,70 L.	4
-------------	----------------	---



Referencia	Artículo	Uds. por caja
120280-2760	FUENTE RECT. 28 Cm.	12
120320-2758	FUENTE RECT. 32 Cm.	6
120380-2762	FUENTE RECT. 38 Cm.	6
121150-0424	RABANERA 15 Cm.	12
121240-7112	RABANERA 24 Cm.	24
125030-2763	CAFETERA 0,30 L.	12
125135-2777	CAFETERA 1,35 L.	4
125031-2749	TAPA CAFETERA 0,30 L.	
126015-2704	LECHERA 0,15 L.	24
126030-2705	LECHERA 0,30 L.	24
127040-2722	TETERA 0,40 L.	12
127041-2739	TAPA TETERA 0,40 L.	