



**Plato Llano ø30 cm**  
 Flat Plate ø11,81"  
 Peso/Weight 910 gr  
 U. Caja/U. Box 6  
 0010600060002

**Plato Llano ø27 cm**  
 Flat Plate ø10,63"  
 Peso/Weight 655 gr  
 U. Caja/U. Box 12  
 0010600000002

**Plato Llano ø25 cm**  
 Flat Plate ø9,84"  
 Peso/Weight 537 gr  
 U. Caja/U. Box 24  
 0010600030002

**Plato Hondo ø22 cm**  
 Deep Plate ø8,66"  
 Peso/Weight 492 gr  
 U. Caja/U. Box 24  
 0010600100002

**Plato Postre ø20 cm**  
 Flat Plate ø7,87"  
 Peso/Weight 418 gr  
 U. Caja/U. Box 24  
 0010600220002

**Plato Pan ø16 cm**  
 Flat Plate ø6,3"  
 Peso/Weight 216 gr  
 U. Caja/U. Box 24  
 0010600310002

**Taza Moka 100 cc**  
 Moka Cup 3,38 oz  
 Peso/Weight 122 gr  
 U. Caja/U. Box 24  
 0010600500002

**Taza Café 150 cc**  
 Coffee Cup 5,07 oz  
 Peso/Weight 133 gr  
 U. Caja/U. Box 24  
 0010600510002

**Plato Moka/Café ø13,5 cm**  
 Moka/Coffee Saucer ø5,31"  
 Peso/Weight 178 gr  
 U. Caja/U. Box 24  
 0010600610002

**Plato Té ø16 cm**  
 Tea Saucer ø6,3"  
 Peso/Weight 238 gr  
 U. Caja/U. Box 24  
 0010600650002

**Taza Té 200 cc**  
 Tea Cup 6,76 oz  
 Peso/Weight 190 gr  
 U. Caja/U. Box 24  
 0010600520002

**Taza Consomé 230 cc**  
 Consomme Cup 7,78 oz  
 Peso/Weight 242 gr  
 U. Caja/U. Box 24  
 0010600540002

