

tazas y platillos
cups & saucers



2,78€
Taza Café 105 cc
Coffee Cup 3,55 oz
Peso/Weight 142 gr
U. Caja/U. Box 24
0001600510000 Turia



tazas y platillos
cups & saucers

2,29€
Taza Moka 100 cc
Moka Cup 3,38 oz
Peso/Weight 122 gr
U. Caja/U. Box 24
0010600500002

2,81€
Taza Café 150 cc
Coffee Cup 5,07 oz
Peso/Weight 133 gr
U. Caja/U. Box 24
0010600510002

2,00€
Plato Moka-Café ø13,5 cm
Moka/Coffee Saucer ø5,31"
Peso/Weight 178 gr
U. Caja/U. Box 24
0010600610002

2,72€
Taza Moka 70 cc
Moka Cup 2,37 oz
Peso/Weight 135 gr
U. Caja/U. Box 24
0003400500002

3,03€
Taza Café 130 cc
Coffee Cup 4,4 oz
Peso/Weight 167 gr
U. Caja/U. Box 24
0003400510002

2,29€
Plato Moka/Café ø12 cm
Moka/Coffee Saucer ø4,72"
Peso/Weight 157 gr
U. Caja/U. Box 24
0003400610002

3,03€
Taza Té 200 cc
Tea Cup 6,76 oz
Peso/Weight 190 gr
U. Caja/U. Box 24
0010600520002

2,67€
Plato Té ø16 cm
Tea Saucer ø6,3"
Peso/Weight 238 gr
U. Caja/U. Box 24
0010600650002

4,28€
Taza Consomé 230 cc
Consomme Cup 7,78 oz
Peso/Weight 242 gr
U. Caja/U. Box 24
0010600540002

3,91€
Taza Moka 95 cc
Moka Cup 3,21 oz
Peso/Weight 126 gr
U. Caja/U. Box 24
0003300500000

3,16€
Plato Moka ø13 cm
Moka Saucer ø5,12"
Peso/Weight 160 gr
U. Caja/U. Box 24
0003300610000

4,46€
Taza Café 135 cc
Coffee Cup 4,56 oz
Peso/Weight 183 gr
U. Caja/U. Box 24
0003300510000

4,05€
Plato Café-Té ø 15 cm
Coffee-Tea Saucer 5,91"
Peso/Weight 213 gr
U. Caja/U. Box 24
0003300650000

4,84€
Taza Té 180 cc
Tea Cup 6,09 oz
Peso/Weight 251 gr
U. Caja/U. Box 24
0003300520000


5,62€
Taza Desayuno 270 cc
Breakfast Cup 9,13 oz
Peso/Weight 264 gr
U. Caja/U. Box 24
0003300530000

7,48€
Taza Consomé 270 cc
Consomme Cup 9,13 oz
Peso/Weight 252 gr
U. Caja/U. Box 24
0003300540000

5,43€
Plato Tazón ø18 cm
Saucer ø7,09"
Peso/Weight 318 gr
U. Caja/U. Box 24
0003300630000

2,61€
Taza Té 2-132 180 cc
Tea Cup 2-132 6,09 oz
Peso/Weight 190 gr
U. Caja/U. Box 24
0000300550002

2,30€
Plato Té 2-138 ø15 cm
Tea Saucer 2-138 ø5,91"
Peso/Weight 179 gr
U. Caja/U. Box 24
0000300650002



3,75€
Taza Té 190 cc
Tea Cup 6,42 oz
Peso/Weight 250 gr
U. Caja/U. Box 24
0003400520002

2,78€
Plato Té ø15 cm
Tea Saucer ø5,91"
Peso/Weight 252 gr
U. Caja/U. Box 24
0003400650002

4,13€
Taza Desayuno 230 cc
Breakfast Cup 7,78 oz
Peso/Weight 266 gr
U. Caja/U. Box 24
0003400530002

3,05€
Plato Tazón ø16 cm
Saucer ø6,3"
Peso/Weight 358 gr
U. Caja/U. Box 24
0003400660002

2,59€
Taza Moka 80 cc
Moka Cup 2,71 oz
Peso/Weight 125 gr
U. Caja/U. Box 24
0001600500000

2,78€
Taza Café 105 cc
Coffee Cup 3,55 oz
Peso/Weight 142 gr
U. Caja/U. Box 24
0001600510000

3,40€
Taza Té 210 cc
Tea Cup 7,10 oz
Peso/Weight 207 gr
U. Caja/U. Box 24
0001600520000

2,52€
Plato Moka-Café ø12,5 cm
Moka-Coffee Saucer ø4,92"
Peso/Weight 146 gr
U. Caja/U. Box 24
0001600600000

3,16€
Plato Té-Desayuno ø15,5 cm
Tea-Breakfast Saucer ø6,10"
Peso/Weight 258 gr
U. Caja/U. Box 24
0001600650000

4,13€
Taza Desayuno 250 cc
Breakfast Cup 8,45 oz
Peso/Weight 283 gr
U. Caja/U. Box 24
0001600530000

1,94€
Taza Moka 2-121 90 cc
Moka Cup 2-121 3,04 oz
Peso/Weight 120 gr
U. Caja/U. Box 24
0000300500002

1,71€
Plato Moka 2-128 ø12 cm
Moka Saucer 2-128 ø4,72"
Peso/Weight 102 gr
U. Caja/U. Box 24
0000300600002

3,16€
Taza Desayuno 2-133 250 cc
Breakfast Cup 2-133 8,45 oz
Peso/Weight 230 gr
U. Caja/U. Box 24
0000300530002

3,96€
Taza Consomé 2-145 300 cc
Consomme Cup 2-145 10,14 oz
Peso/Weight 284 gr
U. Caja/U. Box 24
0000300540002

2,43€
Plato Moka 221 ø12,5 cm
 Moka Saucer 221 ø4,92"
 Peso/Weight 126 gr
 U. Caja/U. Box 24
 0005000600000

2,62€
Plato Café A 221 ø13,5 cm
 Coffee Saucer A 221 ø5,31"
 Peso/Weight 147 gr
 U. Caja/U. Box 24
 0005000620000

2,62€
Plato Café 221 ø13,5 cm
 Coffee Saucer 221 ø5,31"
 Peso/Weight 151 gr
 U. Caja/U. Box 24
 0005000610000

2,79€
Taza Moka 80 cc
 Moka Cup 2,71 oz
 Peso/Weight 121 gr
 U. Caja/U. Box 24
 0005000500000

3,00€
Taza Café 100 cc
 Coffee Cup 3,38 oz
 Peso/Weight 164 gr
 U. Caja/U. Box 24
 0005000510000

3,67€
Taza Té 150 cc
 Tea Cup 5,07 oz
 Peso/Weight 198 gr
 U. Caja/U. Box 24
 0005000520000

3,84€
Taza Caldo 190 cc
 Breakfast Cup 6,42 oz
 Peso/Weight 249 gr
 U. Caja/U. Box 24
 0005000550000

3,30€
Plato Té 221 ø15,5 cm
 Tea Saucer 221 ø6,1"
 Peso/Weight 188 gr
 U. Caja/U. Box 24
 0005000650000

3,96€
Plato Tazón 221 ø17 cm
 Saucer 221 ø6,69"
 Peso/Weight 280 gr
 U. Caja/U. Box 24
 0005000630000

2,79€
Taza Moka 70 cc
 Moka Cup 2,37 oz
 Peso/Weight 123 gr
 U. Caja/U. Box 24
 0005100500000

3,00€
Taza Café 110 cc
 Coffee Cup 3,72 oz
 Peso/Weight 157 gr
 U. Caja/U. Box 24
 0005100510000

3,67€
Taza Té 170 cc
 Tea Cup 5,75 oz
 Peso/Weight 217 gr
 U. Caja/U. Box 24
 0005100520000

3,84€
Taza Caldo 210 cc
 Breakfast Cup 7,10 oz
 Peso/Weight 296 gr
 U. Caja/U. Box 24
 0005100550000

2,92€
Taza Moka 70 cc
 Moka Cup 2,37 oz
 Peso/Weight 119 gr
 U. Caja/U. Box 24
 0003000500000

3,11€
Taza Café 90 cc
 Coffee Cup 3,04 oz
 Peso/Weight 151 gr
 U. Caja/U. Box 24
 0003000510000

3,69€
Taza Té 170 cc
 Tea Cup 5,75 oz
 Peso/Weight 212 gr
 U. Caja/U. Box 24
 0003000520000

4,48€
Taza Desayuno 220 cc
 Breakfast Cup 7,44 oz
 Peso/Weight 255 gr
 U. Caja/U. Box 24
 0003000530000

6,14€
Taza Consomé 240 cc
 Consomme Cup 8,12 oz
 Peso/Weight 246 gr
 U. Caja/U. Box 24
 0003000540000



4,46€
Taza Desayuno 250 cc
 Breakfast Cup 8,45 oz
 Peso/Weight 300 gr
 U. Caja/U. Box 24
 0005000530000

6,18€
Taza Consomé 240 cc
 Consomme Cup 8,12 oz
 Peso/Weight 285 gr
 U. Caja/U. Box 24
 0005000540000



4,18€
Taza Desayuno 500 cc 2-824
Breakfast Cup 16,91 oz 2-824
Peso/Weight 388 gr
U. Caja/U. Box 24
0000601050002

2,11€
Taza Moka 70 cc 2-515
Moka Cup 2,37 oz 2-515
Peso/Weight 141 gr
U. Caja/U. Box 24
0000600500002

2,86€
Taza Te 170 cc 2-516
Tea Cup 5,75 oz 2-516
Peso/Weight 218 gr
U. Caja/U. Box 24
0000600520002

1,42€
Platillo excéntrico 2-504 ø16cm
Eccentric Saucer
2-504 ø6,30"
Peso/Weight 252 gr
U. Caja/U. Box 24
0007000660002

1,38€
Platillo excéntrico 2-503 ø14cm
Eccentric Saucer
2-503 ø5,51"
Peso/Weight 217 gr
U. Caja/U. Box 24
0007100610002

1,24€
Platillo excéntrico 2-500 ø12cm
Eccentric Saucer
2-500 ø4,72"
Peso/Weight 129 gr
U. Caja/U. Box 24
0007200600002

2,11€
Taza moka 70 cc 2-580
Moka Cup 2,37 oz 2-580
Peso/Weight 136 gr
U. Caja/U. Box 24
0000800500002

2,86€
Taza te 170 cc 2-581
Tea Cup 5,75 oz 2-581
Peso/Weight 230 gr
U. Caja/U. Box 24
0000800520002

3,60€
Taza desayuno 250 cc 2-582
Breakfast Cup 8,45 oz 2-582
Peso/Weight 334 gr
U. Caja/U. Box 24
0000800530002

3,75€
Taza Desayuno 350 cc 2-525
Breakfast Cup 11,83 oz 2-525
Peso/Weight 359 gr
U. Caja/U. Box 24
0000600570002

3,60€
Taza Desayuno 250 cc 2-517
Breakfast Cup 8,45 oz 2-517
Peso/Weight 287 gr
U. Caja/U. Box 24
0000600530002

3,75€
Taza Desayuno 300cc 2-1549
Breakfast Cup oz 2-1549
Peso/Weight 423 gr
U. Caja/U. Box 24
0004900530002

3,02€
Taza Te 160 cc 2-1548
Tea Cup oz 2-1548
Peso/Weight 254 gr
U. Caja/U. Box 24
0004900520002

2,24€
Taza Moka 70 cc 2-1547
Moka Cup 2,37 oz 2-1547
Peso/Weight 129 gr
U. Caja/U. Box 24
0004900500002

1,24€
Platillo excéntrico 2-505 ø12 cm
Eccentric Saucer
2-505 ø4,72"
Peso/Weight 127 gr
U. Caja/U. Box 24
0007100600002

1,38€
Platillo excéntrico 2-506 ø14 cm
Eccentric Saucer
2-506 ø5,51"
Peso/Weight 202 gr
U. Caja/U. Box 24
0007000610002

1,42€
Platillo excéntrico 2-504 ø16cm
Eccentric Saucer
2-504 ø6,30"
Peso/Weight 252 gr
U. Caja/U. Box 24
0007000660002

5,37€
Taza Desayuno 250 cc
Breakfast Cup 8,45 oz
Peso/Weight 246 gr
U. Caja/U. Box 24
0005300530000

5,18€
Taza Desayuno 250 cc
Breakfast Cup 8,45 oz
Peso/Weight 284 gr
U. Caja/U. Box 24
0001300530000

3,64€
Taza Té 135 cc
Tea Cup 4,56 oz
Peso/Weight 177 gr
U. Caja/U. Box 24
0001300520000

4,33€
Taza Caldo 210 cc
Breakfast Cup 7,10 oz
Peso/Weight 227 gr
U. Caja/U. Box 24
0001300550000

3,27€
Plato Té/Desayuno ø15 cm
Tea/Breakfast Saucer ø5,91"
Peso/Weight 206 gr
U. Caja/U. Box 24
0001300650000

3,75€
Taza desayuno 350 cc 2-521
Breakfast Cup 11,83 oz 2-521
Peso/Weight 376 gr
U. Caja/U. Box 24
0000800570002

4,18€
Taza desayuno 470 cc 2-1553
Breakfast Cup 15,89 oz 2-1553
Peso/Weight 436 gr
U. Caja/U. Box 24
0000801050002

2,78€
Taza Moka 75 cc
Moka Cup 2,54 oz
Peso/Weight 121 gr
U. Caja/U. Box 24
0001300500000

2,89€
Taza Café 100 cc
Coffee Cup 3,38 oz
Peso/Weight 138 gr
U. Caja/U. Box 24
0001300510000

2,25€
Plato Moka/Café ø12,5 cm
Moka/Coffee Saucer ø4,92"
Peso/Weight 135 gr
U. Caja/U. Box 24
0001300600000





tazas y platillos
cups & saucers